ONFI Technical Errata

Errata ID	**005**
Affected Spec Ver.	**ONFI 2.0**
Corrected Spec Ver.	

Submission info

Name	Company	Date
Amber Huffman	Intel	4/28/2008

Description of the specification technical flaw (add space as needed)

This erratum provides a clarification in the Get Features command definition section that the 00h command is used to start transferring data after use of Read Status (Enhanced) during the tFEAT time.

Description of the correction

Add paragraph 3 to section 5.21 as shown:

5.21 Get Features Definition

The Get Features function is the mechanism the host uses to determine the current settings for a particular feature. This function shall return the current settings for the feature (including modifications that may have been previously made with the Set Features function). Parameters are always transferred on the lower 8-bits of the data bus. After reading the first byte of data, the host shall complete reading all desired data before issuing another command (including Read Status or Read Status Enhanced). Figure 67 defines the Get Features behavior and timings.

When issuing Get Features in the source synchronous data interface, each data byte is received twice. The host shall only latch one copy of each data byte. See section 4.3.2.4.

If Read Status (Enhanced) is used to monitor when the tFEAT time is complete, the host shall issue a command value of 00h to begin transfer of the feature data starting with parameter P1.

Disposition log

4/28/2008	Erratum captured.
6/12/2008	Erratum ratified.

Technical input submitted to the ONFI Workgroup is subject to the terms of the ONFI contributor's agreement.